



## **TRIAD CABLE LIFTS OWNER'S MANUAL**

---

If you find the Triads are not stable enough, then install the locking screw/washer/nut we've provided, as follows:

1. Set up the Triad tripod on a table with the three dowels fully spread. Set the collar ring about 1/2" below the top of the dowels.
2. From above, push the screw down through the gap between the three dowels. It will be easier if you bring the dowel in a little from the fully spread position.
3. Now, spreading the dowels apart as far as possible with one hand, turn the tripod upside down and slip the washer over the end of the screw that is sticking up. You will probably have to tilt the washer 45 degrees or so to get it to slip onto the screw.
4. Still holding the dowels apart with one hand, use the other hand to thread the nut onto the screw with one or two turns. Once the nut is threaded, level the washer between the three legs—you can pry it level with a screwdriver. Then use a Philips screwdriver to tighten the screw while holding the nut with your fingers. You don't have to tighten the screw very hard. Once you have about 1/4" of screw showing through the nut, you're done.